


Starting & Stopping the Engine


3. Make sure the engine stop switch is at RUN.
4. Turn the ignition switch (3) ON.

BELOW HANDLEBAR



(3) ignition switch

5. With the throttle closed, push the start button (4). Release the start button as soon as the engine starts.



(4) start button