


# Piston/Piston Rings/Piston Pin

## Piston Removal

1. Place clean shop towels in the crankcase to keep the piston pin clips, or other parts, from falling into the crankcase.
2. Remove the piston pin clips (1) using a pair of needle-nose pliers.
3. Press the piston pin (2) out of the piston (3), and remove the piston.

Under racing conditions, the piston and rings should be replaced every 6 races or about every 15.0 hours of running. Replace the piston pin every 12 races or about every 30.0 hours of running.



(1) piston pin clips  
(2) piston pin


(3) piston

## Piston Ring Removal

Spread each piston ring (1) and remove by lifting it up at a point just opposite the gap.

### NOTICE

*Do not damage the piston ring by spreading the ends too far.*



(1) piston ring

## Piston/Piston Pin/Piston Ring Inspection

We recommend you consult an official Honda Shop Manual or your Honda dealer for correct Service Limit measurements.