


## Inspection

The reserve tank is inside of front fairing.

Check the coolant level in the reserve tank (1) while the engine is at the normal operating temperature with the scooter in an upright position. If the coolant level is below the LOWER level mark (2), remove the right compartment (page 61) and reserve tank cap (4) and add coolant mixture until it reaches the UPPER level mark (3). Always add coolant to the reserve tank. Do not attempt to add coolant by removing the radiator cap.




(1) Reserve tank

(3) UPPER level mark

(2) LOWER level mark

If the reserve tank is empty, or if coolant loss is excessive, check for leaks and see your Honda dealer for repair.



(1) Reserve tank

(4) Reserve tank cap