

MAINTENANCE

SIDE STAND

Refer to the Maintenance Precautions on page 108.

Perform the following maintenance in accordance with the maintenance schedule.

- Check the spring for damage or loss of tension and the side stand assembly for freedom of movement.
- Check the side stand ignition out-off system:
 1. Sit astride the motorcycle; put the side stand up and the transmission in neutral.
 2. Start the engine and with the clutch lever pulled in, shift the transmission into gear.
 3. Lower the side stand. The engine should stop as you put the side stand down.

If the side stand system does not operate as described, see your authorized Honda dealer for service.

