


Ignition Switch

The ignition switch (1) is below the indicator panel.



(1) Ignition switch

Key Position	Function	Key Removal
LOCK (steering lock)	Steering is locked. Engine and lights cannot be operated.	The key can be removed
P (parking)	For parking the motorcycle near traffic. The taillight and position light are on, but all other lights are off, The engine cannot be started. Steering is locked.	The key can be removed
OFF	Engine and lights cannot be operated.	The key can be removed
ON	The lights can be operated. Engine can be started.	The key cannot be removed