

REMOVAL FROM STORAGE

1. Uncover and clean the scooter.
Change the engine oil if more than 4 months have passed since the start of storage.
2. Charge the battery as required. Install the battery.
3. Drain any excess aerosol rust-inhibiting oil from the fuel tank. Fill the fuel tank with fresh petrol.
4. Perform all Pre-ride Inspection checks (page 41).
Test ride the scooter at low speeds in a safe riding area away from traffic.