

# ELECTRICAL

---

## FUSE REPLACEMENT

Refer to Maintenance Precautions on page 79.

When frequent fuse failure occurs, it usually indicates a short circuit or an overload in the electrical system. See your authorized Honda dealer for repair.

### CAUTION:

- *Turn the ignition switch OFF before checking or replacing fuses to prevent accidental short-circuiting.*

### ▲ WARNING

- *Never use a fuse with a different rating from that specified. Serious damage to the electrical system or a fire may result, causing a dangerous loss of lights or engine power.*

