

Installation Notes:

- Reverse the removal procedure.
- Tighten and torque the following nuts and bolts :
Axle nut torque:
90 N·m (9.0 kg-m , 65 lb-ft)
Brake stopper arm nut torque:
27 N·m (2.7 kg-m , 20 lb-ft)
- Adjust the brake (page 16) and drive chain (page 62).
- Apply the brake several times and check for free wheel rotation after the brake pedal is released.

▲WARNING

- * **If a torque wrench was not used for installation, see your authorized Honda dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.**

CAUTION:

- * **Always replace used cotter pins with new ones.**