

MAINTENANCE SCHEDULE This maintenance schedule is based upon average riding conditions. Machines subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing.	INITIAL SERVICE PERIOD	REGULAR SERVICE PERIOD Perform at every indicated month or mileage interval, whichever occurs first.				
		Month	1	3	6	12
		Mile	500	1,500	3,000	6,000
		Km	1,000	2,500	5,000	10,000
BRAKE CONTROL LINKAGE— Check linkage, and adjust free play if necessary.	●			○		
*WHEEL RIMS AND SPOKES— Check. Tighten spokes and true wheels, if necessary.	●			○		
TIRES— Inspect and check air pressure.	●	○				
FRONT FORK OIL— Drain and refill.	***●				○	
FRONT AND REAR SUSPENSION— Check operation.	●			○		
REAR FORK BUSHING— Grease, check for excessive looseness.				○		
*STEERING HEAD BEARINGS— Adjust.					○	
BATTERY— Check electrolyte level, and add water if necessary.	●		○			
LIGHTING EQUIPMENT— Check and adjust if necessary.	●	○				
ALL NUTS, BOLTS, AND OTHER FASTENERS— Check security and tighten if necessary.	●	○				

Items marked * should be serviced by an authorized Honda dealer, unless the owner has proper tools and is mechanically proficient. Other maintenance items are simple to perform and may be serviced by the owner.

** Initial service period 200 miles.

*** Initial service period 1,500 miles.