


Accessory Socket

The accessory socket is located in the front box. **▶ P.63**
Use accessory devices at your own risk. In no event shall Honda be liable for any damages to your accessory device when in use. Open the cover to access the socket.

Rated capacity is **12W (12V, 1A)**.



- ▶ To prevent the battery from becoming weak (or dead), keep the engine running while drawing current from the socket.
- ▶ Set the headlight on low beam while the socket is in use. The battery may run down or cause damage to the socket.
- ▶ To prevent entry of foreign matter into the socket, be sure to close the cover when the socket is not used.

NOTICE

- Using any heat-generating accessory or improperly rated accessory can damage the socket.
- Do not use the socket in wet conditions, when or while washing or any other wet conditions as these will damage the socket.