



Items	Frequency *1									
	× 1,000 mi	0.6	4	8	12	16	20	24	Regular Replace	Refer to page
	× 1,000 km	1.0	6.4	12.8	19.2	25.6	32.0	38.4		
Fuel Line				I		I		I		-
Throttle Operation				I		I		I		101
Air Cleaner *2					R			R		72
Crankcase Breather *3			C	C	C	C	C	C		102
Spark Plug	Every 16,000 mi (25,600 km): I Every 32,000 mi (51,200 km): R									
Valve Clearance						I				-
Engine Oil		R		R		R		R	1 Year	84
Engine Oil Filter		R				R				86
Engine Idle Speed				I		I		I		-
Radiator Coolant *5				I		I		I	3 Years	88
Cooling System				I		I		I		-
Secondary Air Supply System						I				-
Evaporative Emission Control System *4						I				-

Maintenance Level

 : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Service Manual (P. 140).

 : Technical. In the interest of safety, have your motorcycle serviced by your dealer.

Maintenance Legend

I : Inspect (clean, adjust, lubricate, or replace, if necessary)

C : Clean

R : Replace

L : Lubricate