

## Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, and how to use the throttle, clutch, and brakes. It also provides important information on riding with a passenger or cargo.

To protect your new engine and enjoy optimum performance and service life, refer to Break-in Guidelines (page 234).

To protect the catalytic converter in your motorcycle's exhaust system, avoid extended idling and the use of leaded gasoline.

Safe Riding Precautions .....	66
Starting & Stopping the Engine .....	67
Preparation.....	68
Starting Procedure .....	69
Flooded Engine .....	70
Bank Angle Sensor Ignition Cut-off System .....	70
How to Stop the Engine .....	71
Shifting Gears.....	72
Braking .....	74
Combined ABS ( CBR1000RR ABS ).....	76
Combined ABS Indicator ( CBR1000RR ABS ).....	78
Parking.....	80
Theft-prevention Tips .....	83
Riding with a Passenger or Cargo.....	85