
Instruments



RESET button

Press RESET button to change the speed and mileage units ("mph" & "mile" / "km/h" & "km") for the speedometer, odometer, and tripmeter with the display in the tripmeter A.

Press RESET button to change the coolant temperature unit (" r " / " c ") for the coolant temperature gauge with the display in the tripmeter B.