

Front Wheel

Removal

1. Park on a firm, level surface.
2. Loosen the axle pinch bolts.
3. Loosen the front axle shaft.
4. Support your motorcycle securely and raise the front wheel off the ground using a maintenance stand or a hoist.
5. Remove the front axle shaft, side collars and wheel.
 - Avoid getting grease, oil, or dirt on the disc or pad surfaces.
 - Do not pull the brake lever while the front wheel is removed.

