

Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.

Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ➔ P. 47

| | |
|------------------|---|
| Tires and wheels | Check the air pressure (➔ P. 60), examine tread for wear and damage (➔ P. 60), and check the wheels for damage. |
| Fluid levels | Check the engine oil level (➔ P. 72) and engine coolant level (➔ P. 77). |
| Lights | Check that the headlight, brake light, taillight, and turn signals are working properly. |
| Controls | Check the freeplay of the front and rear brake levers (➔ P. 79), and throttle grip (➔ P. 84). |
| Fuses | Check that you have a full supply of spare fuses. |
| Nuts & bolts | Check the major nuts and bolts, and tighten as needed. |