Indicators & Displays

Maintenance minder indicator

The maintenance minder indicator appears in the display when the mileage or operating hours on your Honda SXS reaches the maintenance interval specified on the maintenance schedule (page 109).

Reset the indicator after each scheduled maintenance is performed. If the scheduled maintenance is performed before the maintenance minder indicator appears, be sure to reset the maintenance minder after performing the scheduled maintenance.

Resetting the indicator:

To reset the indicator, press and continue to hold the mode switch and turn the ignition switch to ON(q). The indicator message will light up, and after 2 seconds will blink twice, the maintenance minder indicator is reset.

Also the maintenance tripmeter and maintenance hour meter will reset.

See more details about maintenance minder indicator on page 107.

maintenance minder indicator (P) GEAR GEAR ((R)(R)(I) (N)I) (N) (<u>T</u> mode switch mode switch maintenance tripmeter maintenance hour meter