

Have your tires replaced by your dealer. For recommended tires, air pressure and minimum tread depth, see “Specifications.”

 P. 124

Follow these guidelines whenever you replace tires.

- Use the recommended tires or equivalents of the same size, construction, speed rating, and load range.
- Have the wheel balanced with Honda Genuine balance weight or equivalent after the tire is installed.
- Remember to replace the inner tube whenever you replace a tire. The old tube will properly be stretched, and it could fail if installed in a new tire.

WARNING

Installing improper tires on your motorcycle can adversely affect handling and stability, and can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tires recommended in this owner's manual.