

Storing Your Honda

7. Inflate the tires to their recommended pressures (page 121).
8. Store your motorcycle in an unheated area, free of dampness, away from sunlight, with a minimum of daily temperature variation.
9. Place your motorcycle on blocks to lift both tires off the floor.
10. Cover your motorcycle with a porous material. Avoid using plastic or similar non-breathing, coated materials that restrict air flow and allow heat and moisture to accumulate.

Removal from Storage

Refer to *Safety Precautions* on page 58 .

1. Uncover and clean your motorcycle.
2. If your motorcycle has been stored for more than four months — change the engine oil (page 85).
3. If your motorcycle has been stored for more than two months — ask your dealer to drain and replace the fuel.
4. Charge the battery (page 134) as required. Install the battery.
5. Perform a pre-ride inspection (page 29), then test-ride your motorcycle at low speeds.