


Fuel Valve

The fuel valve (1) is located under the left side of the fuel tank. With the valve set in the OFF position, fuel supply is cut off. The valve should be set in this position when the motorcycle is not in use.

Turn to the ON (straight down) position for normal riding (gasoline will flow to the carburetor).

Turning the fuel valve to the RES position allows fuel to flow from the reserve supply.



Válvula de combustible

El depósito de combustible está dotado de una válvula de combustible (1) situada debajo del lado izquierdo. Con la válvula en posición OFF, la alimentación del combustible cesará. La válvula deberá colocarse en esta posición al estacionar la motocicleta.

Colóquela en posición ON (Hacia abajo) para la conducción normal (la gasolina circulará hacia el carburador).

Girando la válvula de combustible hasta la posición RES correrá el combustible desde el depósito de reserva.