

Tires – Check the air pressure and tires for wear or damage. (See page 124)

Battery electrolyte – Check the level and add if necessary. (See page 120)

Throttle operation – Check the throttle operation, cable routing and free play. Correct or replace if necessary. (See page 82)

Lighting – See that all lights operate properly.

Drive chain – Check condition of drive chain and measure the chain tension. Adjust if the chain tension is incorrect. Lubricate if it appears dry. Replace if it is badly worn or damaged. (see page 90)

---

Llantas – Revise la presión de aire, estado de desgaste o daño de las llantas. (pág. 124)

Electrólito de la batería – Revise el nivel y agregue, si es necesario. (pág. 120)

Funcionamiento del acelerador – Revise el funcionamiento del acelerador, instalación de sus cables y juego libre. Corrija o reemplace, si es necesario. (pág. 82)

Iluminación – Revise si todas las lámparas funcionan normalmente.

Cadena de transmisión – Compruebe el estado de la cadena de transmisión y mida la tensión de la misma. Ajuste la tensión si es incorrecta. Lubrique la cadena si está seca. Reemplácela si está visiblemente dañada o desgastada. (pág. 90)