

Drive belt replacement

1. Apply the parking brake to hold the drive shaft.
2. Loosen the wing nut to remove the belt converter safety guard.
3. With both hands, rotate the movable face of the driven pulley in the opposite direction of normal operation, to move it sideways, in order to create enough drive belt slack to remove the drive belt.
4. Take out the belt over the driven movable face ① starting with the lower side and remove it from the drive pulley.

Remplacement de la courroie d'entraînement

1. Serrer le frein de stationnement pour retenir l'arbre de transmission.
2. Desserrer l'écrou ailé pour enlever l'appareil protecteur du convertisseur de la courroie.
3. A l'aide des deux mains, tourner la partie mobile de la poulie d'entraînement dans la direction opposée au fonctionnement normal, afin de la déplacer latéralement pour créer suffisamment de jeu à la courroie d'entraînement pour pouvoir l'enlever.
4. Enlever la courroie se trouvant au-dessus de la partie mobile d'entraînement ① en commençant par la partie inférieure et l'enlever de la poulie.

