


Valve Tappet Clearance

The checking or adjusting of the tappet clearance should be performed while the engine is cold.

1. Remove the left crankcase cover and cylinder head cover.
2. Rotate the generator rotor counterclockwise and align the "T" mark (1) with the index mark (2). Make sure the piston is at TDC of the compression stroke by feeling the tappets with fingers. If the tappets are free, it is an indication that the piston is at TDC of the compression stroke. If the tappets are tight, rotate the generator rotor 360° and realign the marks.



Luz de válvulas

La revisión o ajuste de la luz de válvulas deberá efectuarse mientras que el motor esté frío.

1. Quite la cubierta del cárter izquierdo y la de la culata de cilindro.
2. Haga girar el rotor de generador en el sentido contrario del movimiento de manecillas del reloj y alinee la marca "T" (1) con la marca de índice (2). Asegúrese de que el pistón esté en el punto muerto superior en la carrera de compresión tocando los taqués con los dedos. Si los taqués están libres, es una indicación de que el pistón esté en el punto muerto superior de la carrera de compresión. Si se sienten los taqués rígidos, haga girar el rotor de generador por 360° y alinee las marcas de nuevo.