

Tiers – Check the air pressure and tires for wear or damage. (See page 94.)

Battery electrolyte – Check the level and add if necessary. (See page 90.)

Throttle operation – Check the throttle operation, cable routing and free play. Correct or replace if necessary. (See page 66.)

Lighting – See that all lights operate properly. (See page 14.)

Drive chain – Check condition of drive chain and measure the chain tension. Adjust if the chain tension is incorrect. Lubricate if it appears dry. Replace if it is badly worn or damaged. (See page 72.)

---

Llantas – Revise la presión de aire, estado de desgaste o daño de las llantas. (pág. 94)

Electrólito de la batería – Revise el nivel y agregue, si es necesario. (pág. 90)

Funcionamiento del acelerador – Revise el funcionamiento del acelerador, instalación de sus cables y juego libre. Corrija o reemplácelo, si es necesario. (pág. 66)

Iluminación – Revise si todas las lámparas funcionan normalmente. (pág. 14)

Cadena de transmisión – Mida el juego; la dureza de operación debido a lubricación inadecuada y otras condiciones esenciales para suave funcionamiento. (pág. 72 )