Switches

Shift up switch (+)
To shift up the gear. **➡P.45**

Engine stop switch
Should normally remain in the ◯ (Run) position.
▶ In an emergency, switch to the ⊗ (Stop) position (the starter motor will not operate) to stop the engine.

A/M switch
To shift between the AT MODE and MT MODE. **➡P.44**

N-D switch
To shift between Neutral and AT MODE. **➡P.44**

Shift down switch (-)
To shift down the gear. **➡P.45**
⇦⇨ Turn signal switch
▶ Pressing the switch turns the turn signal off.
➷ Horn button

Headlight dimmer switch
- ≡◗ : High beam
- ≡◗ : Low beam
- ≡◗**PASS** : Flashes the high beam headlight.

⑤ Start button

⚠ Hazard switch
Switchable when the ignition switch is in the ON position. Can be turned to off regardless of the ignition switch position.
▶ The signals continue flashing with the ignition switch is in the OFF or LOCK position after the hazard switch is on.