PART NAME INDEX

Part name	Page	Ref.
CLAMP, TUBE	67	16
CLIP, COUPLER	76	35
		36
		37
CLIP, HARNESS BAND	72	10
CLIP, PISTON PIN, 12MM	44	5
CLIP, SNAP FITTING	53	12
	56	11
CLIP, TUBE	40	17
	43	30
	67	15
		17
CLIP, VALVE GUIDE	27	3
COIL COMP., IGNITION	75	2
COLLAR A, HANDLE SETTING	53	10
COLLAR B, HANDLE SETTING	53	11
COLLAR,THROTTLE BODY COVER	45	15
COLLAR, 8MM	78	7
COLLAR, AIR CLEANER MOUNTING	57	1
COLLAR, AIR CLEANER SETTING	67	1
COLLAR, FR. DISTANCE	63	5
COLLAR, FR. WHEEL SIDE	63	3
		4
COLLAR, HORN SETTING	75	16
COLLAR, KICK BOSS	36	12
COLLAR, LUGGAGE BOX	60	2
		3
COLLAR, MUFFLER PROTECTOR	68	4
COLLAR, RR. FENDER	67	11
COLLAR, SEAL	37	13
COLLAR, SPRING	37	14
COLLAR, TAILLIGHT SETTING	25	6
CONTROL UNIT, ENGINE	75	1
COTTER, VALVE	29	12
COUNTERSHAFT	39	6
COVER COMP., BATTERY	74	13
COVER COMP., FAN	25	1
COVER COMP., HEAD	26	1
COVER COMP., LICENSE	72	6
COVER COMP., SPEEDOMETER	53	5
COVER COMP., THROTTLE BODY	45	5
COVER SET, FR.	56	1
COVER SET, FR. HANDLE	53	3
COVER SET, L. BODY	59	4
COVER SET, R. BODY	59	2
COVER SUB ASSY., AIR CLEANER	67	8
COVER, CABLE	75	14
COVER, CENTER	59	1
COVER, ENGINE CONTROL UNIT	76	39
COVER, FR. LOWER	56	3
COVER, FR. TOP	56	2
COVER, FUEL TANK	66	9
COVER, GRIP END	53	2
COVER, INNER LOWER	56	7
COVER, INNER UPPER	56	5
COVER, LUGGAGE BOX	60	5
COVER, L. BODY SIDE	59	5
COVER, L. BRAKE LEVER BRACKET	49	19
COVER, L. SIDE	35	1
COVER, OIL SCREEN	42	9
COVER, RR. CENTER	59	6
COVER, RR. HANDLE	53	4
COVER, R. BODY SIDE	59	3
COVER, SEAL	76	24
		25
COVER, SEAT CATCH	65	8
COVER, UNDER	56	4
CRANKCASE COMP., L.	42	2
CRANKCASE COMP., R.	41	1
CRANKSHAFT COMP.	44	1
CUSHION ASSY., RR.	70	1
CUSHION A, BATTERY	74	9
CUSHION B, BATTERY	74	10
CUSHION C, BATTERY	74	11
CYLINDER ASSY., FR. MASTER	51	6
CYLINDER COMP.	32	1
CYLINDER SET, MASTER	51	13
[D]		
DIAPHRAGM	51	11
DISK, FR. BRAKE	63	8
DOWEL PIN, 8X10	26	5
	35	12
DOWEL PIN, 8X14	40	15
DOWEL PIN, 8X20	41	15
DOWEL PIN, SPECIAL, 8X12	42	21
DOWEL PIN, SPECIAL, 8X14	27	11
	32	3
DRIVER, SCREW	79	2
DRIVESHAFT	39	5
DUCT, AIR CLEANER	67	4
DUCT, L. COVER	35	3
DUST SEAL, 21X32X5	63	12
DUST SEAL, STEERING HEAD	54	8
[E]		
ELEMENT COMP., AIR CLEANER	67	2
EMBLEM, PRODUCT	53	15
EQUALIZER COMP.	50	21
E-RING, 3MM	50	30
[F]		
FACE COMP., MOVABLE DRIVE	36	5
FACE SET, DRIVEN	37	8
FACE SET, MOVABLE DRIVEN	37	9
FACE, DRIVE	36	2
FAN COMP., COOLING	33	1
FENDER SET, FR.	55	1
FENDER, RR.	73	5
FILTER SET	66	3
FLYWHEEL COMP.	33	2
FORK ASSY., L. FR.	61	13
FORK ASSY., R. FR.	61	1
FUEL UNIT	66	13
FUSE, BLADE	74	2
		3
		4
	75	17
		18
		19
[G]		
GASKET COMP., CYLINDER HEAD COVER	26	2
GASKET, CYLINDER	32	2
GASKET, CYLINDER HEAD	27	4
GASKET, EX. PIPE	68	1
GASKET, MISSION CASE	39	4
GASKET, OIL SCREEN COVER	42	13
GASKET, TENSIONER LIFTER	31	5
GAUGE, OIL LEVEL	41	6
GEAR COMP., FINAL	39	8
GEAR COMP., KICK DRIVEN	36	9
GEAR, COUNTER	39	7
GEAR, OIL PUMP DRIVEN	34	3
GRIP	79	3
GRIP COMP., THROTTLE	49	14
GRIP, L. HANDLE	49	15
GROMMET, SIDE COVER	72	9
GROMMET, TENSIONER HOLE	25	11
GUARD, HEAT	68	3
GUARD, SPLASH	73	3
GUIDE, CAM CHAIN	31	6
GUIDE, HARNESS	76	31
GUIDE, VALVE	27	2
[H]		
HARNESS, WIRE	75	4
HEADLIGHT ASSY.	46	1
HEAD COMP., CYLINDER	27	1
HOLDER	71	9
HOLDER, MASTER CYLINDER	49	13
	51	10
HOOK, LUGGAGE	56	6
HORN COMP.	75	15
HOSE COMP., FR. BRAKE	51	3
HOSE COMP., FUEL FEED	66	12
HOUSING, UNDER THROTTLE	49	17
HOUSING, UPPER THROTTLE	49	16
[I]		
INJECTOR ASSY., FUEL	45	8
INSULATOR, IN. PIPE	45	13
[J]		
JET COMP., PISTON	41	5
JOINT B, BRAKE ARM	64	12
JOINT COMP., INJECTOR	45	14