

8. Remove the old sealing washer (2) and install a new sealing washer on the drain bolt.
9. Install the oil drain bolt and tighten to the specified torque:  
**18 lbf·ft (25 N·m , 2.5 kgf·m)**
10. Pour the recommended oil into the crankcase, approximately:  
**0.6 US qt (0.6 l)**
11. Install the oil filler cap/dipstick securely.
12. Start the engine. Let it idle 3-5 minutes, then turn it off.
13. With the motorcycle held upright on level ground, check the oil level.  
If needed, add oil (page 61 ) until it reaches the upper level mark. (Do not overfill.)
14. Check for oil leaks.