

10. Reinstall the right muffler.

- Before installing the muffler, replace the muffler gasket with a new gasket.

Tighten the nuts and bolts to the specified torques:

exhaust pipe joint nut:

18 lbf·ft (25 N·m , 2.5 kgf·m)

muffler bracket bolt:

20 lbf·ft (27 N·m , 2.7 kgf·m)

muffler bracket nut:

33 lbf·ft (44 N·m , 4.5 kgf·m)

footpeg bracket bolt and nut:

29 lbf·ft (39 N·m , 4.0 kgf·m)

If a torque wrench was not used for installation, see your Honda dealer as soon as possible to verify proper assembly.

Improper assembly may lead to loss of braking capability.