

Install the removed parts.

▲WARNING

*** If a torque wrench was not used for installation, see your Honda dealer as soon as possible to verify proper assembly.**

- ① Install the subframe. Tighten the three bolt to the specified torque:
Subframe upper bolt (15):
26 N·m (2.7 kgf·m , 20 lbf·ft)
Subframe lower side bolts (13) (14):
42 N·m (4.3 kgf·m , 31 lbf·ft)
- ② Connect the electrical connectors by matching the cable colours.
- ③ Reinstall the band and the clip.
- ④ Tighten the air cleaner connecting tube clamp and the rear brake fluid reservoir stay mount bolt.

- ⑤ Install the muffler and tighten the bolts. Be careful not to damage the packing installed inside the muffler clamp. Tighten to the specified torque:
Muffler clamp bolt (3):
20 N·m (2.0 kgf·m , 14 lbf·ft)
Muffler bolt (lower) (4):
32 N·m (3.3 kgf·m , 24 lbf·ft)
Muffler bolt (upper) (5):
32 N·m (3.3 kgf·m , 24 lbf·ft)
- ⑥ Reinstall the side cover, chain cover and seat.