

14. Install the removed parts.

- ① Install the subframe. Tighten the three bolt to the specified torque:  
Subframe upper bolt (14):  
26 N·m (2.7 kgf·m , 20 lbf·ft)  
Subframe lower side bolts (12) (13):  
42 N·m (4.3 kgf·m , 31 lbf·ft)
- ② Connect the electrical connectors by matching the cable colours.
- ③ Reinstall the band and the clip.
- ④ Tighten the air cleaner connecting tube clamp.

- ⑤ Install the muffler and tighten the bolts. Be careful not to damage the packing installed inside the muffler clamp. Tighten the specified torque:  
Muffler clamp bolt (4):  
20 N·m (2.0 kgf·m , 14 lbf·ft)  
Muffler bolt (lower) (5):  
32 N·m (3.3 kgf·m , 24 lbf·ft)  
Muffler bolt (upper) (6):  
32 N·m (3.3 kgf·m , 24 lbf·ft)

If a torque wrench is not used for this installation, see your Honda dealer as soon as possible to verify proper assembly.

- ⑥ Reinstall the side cover, chain cover and seat.