

Front Wheel/Suspension/Steering

Bend down the opposite tabs of a new lock washer and install it onto the steering adjustment nut aligning the tabs with the grooves in the adjustment nut.

Finger tighten the lock nut all the way. Hold the adjustment nut and further tighten the lock nut within 1/4 turn (90°) enough to align its grooves with the lock washer tabs.

Bend the lock washer tabs up into the lock nut grooves.

