## **OPERATION**

page	<u>.</u>
1	MOTORCYCLE SAFETY
1	IMPORTANT SAFETY
	INFORMATION
2	PROTECTIVE APPAREL
4	LOAD LIMITS AND GUIDELINES
0	DADTC LOCATION
	PARTS LOCATION
11	INSTRUMENTS AND
	INDICATORS
400	MALON GOLDONNING
4.7	MATOR COMPONENTS
47	MAJOR COMPONENTS
47	(Information you need to operate
47	
47	(Information you need to operate this motorcycle)
47	(Information you need to operate this motorcycle)
47 51	(Information you need to operate this motorcycle) SUSPENSION
47 51 52	(Information you need to operate this motorcycle) SUSPENSION HANDLEBAR POSITION
47 51 52 55	(Information you need to operate this motorcycle) SUSPENSION HANDLEBAR POSITION BRAKES
47 51 52 55 57	(Information you need to operate this motorcycle) SUSPENSION HANDLEBAR POSITION BRAKES CLUTCH
47 51 52 55 57 59	(Information you need to operate this motorcycle) SUSPENSION HANDLEBAR POSITION BRAKES CLUTCH COOLANT
47 51 52 55 57 59	(Information you need to operate this motorcycle) SUSPENSION HANDLEBAR POSITION BRAKES CLUTCH COOLANT FUEL

page 69 ESSENTIAL INDIVIDUAL COMPONENTS

69 IGNITION SWITCH

70 KEYS

72 IMMOBILIZER SYSTEM (HISS)

75 RIGHT HANDLEBAR CONTROLS

77 LEFT HANDLEBAR CONTROLS