


PARTS LOCATION

Odometer/Tripmeter


If the ceremony display is turned OFF, the initial display is odometer/tripmeter.

- ODO (Odometer) — shows the total miles (For E type) or kilometer (Except E type) ridden.
- TRIP (Tripmeter) — shows the number of miles (For E type) or



The tripmeter will show mileage in two sub modes, “TRIP A” and “TRIP B.”

Push the TRIP button to select the “TRIP A” or “TRIP B” mode.



To reset the tripmeter, push and hold the TRIP button with the display in the “TRIP A” or “TRIP B” mode.

