
Cruise Control Switch

The Cruise Control automates the function of the throttle to maintain your motorcycle at a constant speed. This can be a convenience on long trips, but it can also be a danger if there are any other vehicles on the the road or if the road is unfamiliar.

As its name implies, it is meant for cruising on straight, uncongested highways or freeways. It is not recommended to be used in traffic, on winding roads or in bad weather conditions where the rider should have total control of the throttle.

⚠ WARNING

Improper use of the cruise control can lead to a crash.

Use the cruise control only when traveling on open highways in good weather.

To Set the Cruise Control:

The Cruise Control system allows you to set and automatically maintain any speed between 48 – 161 km/h (30 – 100 mph) in 4th and OD.

Push the CRUISE CONTROL master switch: the indicator light will come on. Accelerate to the desired speed, then push the SET/DECEL switch. The Cruise Control set light on the instrument panel will come on.

