


HELMET HOLDER LOCK/SUB TOOL KIT COMPARTMENT

The storage compartment is located behind the right side of the rear cowl. The helmet holder lock and sub tool kit should be stored in the compartment.

To open the compartment:

1. Insert the ignition key (1) into the lid lock (2) and turn it counterclockwise.
2. Pull the lower end of the compartment lid and open it.



(1) Ignition key

(2) Lid lock