

## Checking the Drive Chain Wear

If the drive chain slack is excessive when the rear axle is moved to the furthest limit of adjustment, the drive chain is worn and must be replaced.

### Replacement drive chain:

DID420AD-104RB  
KMC420JB-104

If necessary have the drive chain replaced by your dealer.

## Removal and Cleaning the Drive Chain

When the drive chain becomes dirty, it should be removed and cleaned prior to lubrication.

1. With the engine off, carefully remove the master link retaining clip with a pair of pliers. Do not bend or twist the clip. Remove the master link. Remove the drive chain from the motorcycle.

