

PRE-RIDE INSPECTION

WARNING

** If the Pre-ride Inspection is not performed, serious damage or an accident may result.*

Inspect your ATC110 every day before you start the engine. The items listed here will only take a few minutes, and in the long run they can save time, expense, and possibly your life.

1. Engine oil level – add engine oil if required (page 12). Check for leaks.
2. Fuel level – fill fuel tank when necessary (page 11). Check for leaks.
3. Brake – check operation. Adjust free play if necessary (page 42).
4. Tires – check condition and pressure (page 14).
5. Drive chain – check condition and slack (page 44). Adjust and lubricate if necessary.
6. Throttle – check for smooth opening and closing in all steering positions (page 6).
7. Headlight switch – check for proper function (page 5).

8. Ignition switch – check for proper function (page 5).
9. Nuts, Bolts, Fasteners – check wheels to see that axle nuts are tightened and secured by cotter pins. Check security of all other nuts, bolts and fasteners.

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.