

OPERATION

PRE-RIDE INSPECTION

WARNING

* *If the Pre-ride Inspection is not performed, serious damage or an accident may result.*

Inspect your ATC200X every day before you start the engine. The items listed here will only take a few minutes to check, and in the long run they can save time expense and possibly your life.

1. Fuel level-fill fuel the tank when necessary (page 10). Check for leaks.
2. Brakes-check operation and fluid level (page 46–50).
3. Tires-check condition and pressure (page 13).
4. Drive chain-check condition (particularly the master link) and slack (page 53). If necessary, adjust and lubricate (page 53).
Adjust and lubricate if necessary (particularly the master link). (page 51).
5. Throttle-check for smooth opening and closing in all steering positions (page 50).
6. Headlight switch-check for proper function (page 5).
7. Ignition switch-check for proper function (page 5).

8. Nuts, bolts, fasteners-check wheels to see that axle nuts are tightened and secured by cotter pins. Check the security of all other nuts, bolts and fasteners.

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.