

//////////////////// MAIN TENANCE //////////////////////

MAINTENANCE SCHEDULE

The maintenance intervals shown in the following schedule are based upon average riding conditions. ATC's subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing.

Perform the Pre-ride Inspection (page 18) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace L: Lubricate A: Adjust			INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	ENGINE OIL	NOTE(1),(2)	R	R	35
	ENGINE OIL FILTER SCREEN		C	C	35
*	ENGINE OIL FILTER ROTOR			C	37
	AIR CLEANER ELEMENT	NOTE (2)		C	45
	SPARK PLUG			I	44
*	VALVE CLEARANCE		I	I	39
*	CAM CHAIN TENSIONER		A	A	55
*	CARBURETOR		I	I	41
	FUEL LINE		I: (EVERY YEAR)		38
*	FUEL FILTER		C:(EVERY YEAR)		38
	THROTTLE OPERATION		I	I	52

* SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND IS MECHANICALLY QUALIFIED.

** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.