

7. Fill the crankcase with approximately 1.2 (1.27 US qt) of the recommended oil (page 12).
 8. Start the engine and let it idle a few minutes.
 9. Stop the engine and check that the oil level is at the upper mark on the dipstick with the ATC upright.
- Check that there are no oil leaks.