

7. Fill the crankcase with approximately 1.1 (1.16 US qt) of the recommended oil (page 13).
8. Start the engine and let it idle a few minutes.
9. Stop the engine and check that the oil level is at the upper mark on the dipstick with the ATC upright.
Check that there are no oil leaks.