

## RIDING

### WARNING

- \* Review ATC Safety (page 1) before you ride.
- \* Avoid "wheelies" and jumping as they cause loss of control.
- \* Ride with your feet on the foot pegs at all times. If your feet are removed from the pegs to touch the ground while the ATC is moving, they may come in contact with the rear wheels.

Under normal riding conditions it is not necessary or desirable to touch the ground for balance.

For your initial riding practice, select a safe area free of obstacles and with an even surface. Avoid paved surfaces as they make learning to maneuver more difficult, and will also significantly shorten tire life.

1. After the engine has been warmed up, release the parking brake. The machine is ready for riding.
2. While the engine is idling, depress the gear change pedal to shift into low (1st) gear.
3. Increase engine speed by opening the throttle.
4. When the speed increases, close the throttle and shift to 2nd gear by depressing the gear change pedal.

### CAUTION:


- \* Do not shift gears without closing the throttle.

The engine and drive train could be damaged by overspeed and shock.

5. This sequence is repeated to progressively shift to 3rd, 4th and top (5th) gear.

### CAUTION:

- \* Do not tow the vehicle or coast for long distances while the engine is off. The transmission will not be properly lubricated and damage may result.



Shifting sequence