

OPERATION

PRE-RIDE INSPECTION

WARNING

** If the Pre-ride Inspection is not performed, serious damage or an accident may result.*

Inspect your ATC 200E every day before you start the engine. The items listed here will only take a few minutes, and in the long run they can save time, expense, and possibly your life.

1. Engine oil level – check the level and if required, add engine oil (page 19). Check for leaks.
2. Fuel level – fill the fuel tank when necessary (page 16). Check for leaks.
3. Brakes – check operation. Adjust free play if necessary (page 48).
4. Tires – check condition and pressure (page 21).
5. Drive chain – check condition and slack (page 56). Adjust and lubricate if necessary.
6. Throttle – check for smooth opening and closing in all steering positions (page 9).
7. Headlight – check for proper function (page 9).

8. Engine stop switch – check for proper function (page 7).
9. Nuts, Bolts, Fasteners – check wheels to see that axle nuts are tightened and secured by cotter pins. Check the security of all other nuts, bolts and fasteners.

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.