

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust L: Lubricate		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	RADIATOR COOLANT		I, R* (EVERY 2 YEARS)	16
*	RADIATOR CORE	NOTE (3)	I	—
*	COOLING SYSTEM HOSE AND CONNECTIONS		I	—
	FUEL LINE		I: (EVERY YEAR)	42
*	FUEL FILTER		C: (EVERY YEAR)	42
	THROTTLE OPERATION		I	54
	DRIVE CHAIN	NOTE (2), (3)	I, L	54
	CHAIN SLIDER		I	56
*	FRONT FORK OIL		R: (EVERY YEAR)	—
*	SUSPENSION		I	—
	SWINGARM BEARING		I, L	—
	FRONT AND REAR BRAKE FLUID		I	I, R*: (EVERY YEAR) 50
*	FRONT AND REAR BRAKE PAD	NOTE (2), (3)	I: (EVERY YEAR)	52