

# CONTENTS

---

<b>SERIAL NUMBER LOCATIONS</b> . . . . .	1	Tires . . . . .	15
<b>NOMENCLATURE</b> . . . . .	2	<b>PRE-RIDE INSPECTION</b> . . . . .	16
<b>OPERATING INSTRUCTIONS</b> . . . . .	4	<b>STARTING THE ENGINE</b> . . . . .	17
Ignition/Engine Stop Switch . . . . .	4	<b>BREAK-IN PROCEDURE</b> . . . . .	19
Rear Brake Lever . . . . .	4	<b>RIDING</b> . . . . .	19
Gear Change Pedal . . . . .	5	<b>PARKING</b> . . . . .	19
Neutral Indicator . . . . .	6	<b>STORAGE</b> . . . . .	20
Choke Lever . . . . .	7	<b>MAINTENANCE</b> . . . . .	21
Fuel Valve . . . . .	8	Maintenance Schedule . . . . .	21
Fuel Tank . . . . .	9	Tool Kit . . . . .	23
Fuel Drain . . . . .	10	<b>MAINTENANCE OPERATIONS</b> . . . . .	24
Oil Recommendation . . . . .	11	Engine Oil level . . . . .	24
Viscosity . . . . .	11	Engine Oil Change . . . . .	24
Engine Oil Level . . . . .	12	Brake Adjustment . . . . .	26
Throttle Lever . . . . .	12	Drive Chain Adjustment . . . . .	27
Speed Limiter . . . . .	13	Drive Chain Lubrication . . . . .	28
Step Guard . . . . .	14	Valve Clearance Adjustment . . . . .	29