

PRE-RIDE INSPECTION

WARNING

If the Pre-ride Inspection is not performed, serious damage or an accident may result.

Inspect your **ATC 70** every day before you ride it. The items listed here will only take a few minutes to check and, in the long run, can save time, expense, and possibly your life.

1. Engine oil level—If necessary, add engine oil (page 16). Check for leaks.
2. Fuel level — fill the fuel tank when necessary (page 13). Check for leaks.
3. Brake lever—check operation. If necessary, adjust free play. (page 40).
4. Tires—check condition and pressure (page 19-20).

5. Drive chain—check condition and slack (pages 42–43).. If necessary, adjust and lubricate.
 6. Throttle—check for smooth opening and closing in all steering positions.
 7. Engine stop switch—check for proper function before riding (page 8).
 8. Nuts, Bolts, Fasteners—check the wheels to see that the axle nuts are tightened and secured by cotter pins. Check the security of all other nuts, bolts and fasteners.
- Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.