

**REGULAR  
SERVICE PERIOD  
EVERY 30  
OPERATING DAYS**

**NOTE**  
Change oil every  
30 operating days  
or every 3  
months, which-  
ever occurs first.

**EVERY YEAR**

- ENGINE OIL - Change.
  - SPARK PLUG - Clean and adjust gap, or replace if necessary
  - \*CONTACT POINTS AND IGNITION TIMING - Clean, check, and adjust or replace if necessary.
  - \*VALVE TAPPET CLEARANCE - Check and adjust if necessary.
  - \*CAM CHAIN TENSION - Adjust
  - POLYURETHANE FOAM AIR FILTER ELEMENT - Clean and oil. Service more frequently if operated in dusty areas.
  - \*CARBURETOR - Check and adjust if necessary.
  - THROTTLE OPERATION - Inspect cable. Check and adjust free play.
  - \*CLUTCH - Check operation and adjust if necessary.
  - DRIVE CHAIN - Check, lubricate, and adjust if necessary.
  - BRAKE CONTROL LINKAGE - Check linkage and adjust if necessary.
  - TIRES - Inspect and check air pressure.
  - SPARK ARRESTOR - Purge
  - LIGHTING EQUIPMENT - Check.
  - ALL NUTS, BOLTS, AND OTHER FASTENERS - Check security and tighten if necessary
- 
- FUEL FILTER SCREEN - Clean.
  - FUEL LINE(S) - Check.
  - \*STEERING HEAD BEARINGS - Adjust.
  - \*BRAKE SHOES - Inspect and replace if worn.