FREQUENCY		WHICHEVER → COMES		ODOMETER READING [NOTE (1)]							
		FIRST	imes 1,000 km	1	6	12	18	24	30	36	Refer
			× 1,000 mi	0.6	4	8	12	16	20	24	to
ITEM		NOTE	MONTH		6_	12	18	24	30	36	Page
* FUEL LINE						I		_I		I	
* THROTTLE OPERATION						I		_1		I	128
AIR CLEANER		NOTE (2)					C			C	131
SPARK PLUGS						I		R		I	125
* CHOKE OPERATION						I		I		I	
* VALVE CLEARANCE								_I			
ENGINE OIL				R		R		R		R	117
ENGINE OIL FILTER				R	Ī.,	R		_R		R	120
* ENGINE IDLE SPEED				I		I		_ I _		I	129
CRANKCASE BREATHER		NOTE (3)			I	I	I	I	I	I	123
RADIATOR COOLANT		NOTE (4)	L'			I		_I_		R	57
* COOLING SYSTEM						I		_ I		I	
* SECONDARY AIR SUPPLY	SYSTEM					I		I		Í	