







Motorcycle Safety

## **Image Labels**



## **RADIATOR CAP LABEL DANGER** Except U type

NEVER OPEN WHEN HOT.

Hot coolant will scald you.

Relief pressure valve begins to open at 1.1 kgf/cm<sup>2</sup>.



## **ACCESSORIES AND LOADING WARNING LABEL** WARNING Except U type

**ACCESSORIES AND LOADING** 

- The safety stability and handling of this motorcycle may be affected by the addition of accessories and luggage.
- Read carefully the instructions contained in user's manual and installation guide before installing any accessory.
- The total weight of accessories and luggage added to rider's and passenger's weight should not exceed 182 kg (401 lb), which is the maximum weight capacity.
- The luggage weight must not exceed 11 kg (24 lb) under any circumstances.
- The fitting of large fork-mounted or large handlebar mounted fairing is not recommended.







