


FUEL TANK

The fuel tank capacity is 3.7 U.S. gallons (14ℓ) including the 1.0 U.S. gallon (4ℓ) in the reserve supply. Press down on the cap ① and then push in the lock to



① Fuel tank cap

Ⓐ Press down

Ⓑ Push in

open the fuel tank cap.

WARNING:

Gasoline is flammable, and explosive under certain conditions. Always stop the engine and do not smoke or allow open flames or sparks near the motorcycle when refueling.

NOTE:

It is recommended that 90 or higher octane number gasoline containing a small percentage of lead.

Do not mix oil with the gasoline.

When refueling the tank, avoid overfilling into tank filler cap neck.