

ITEMS	FREQUENCY	WHICHEVER → COMES		ODOMETER READING [NOTE (1)]								Refer to pages
		FIRST ↓	x 1,000 km	1	6	12	18	24	30	36		
			x 1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
				EVERY 1,000 km (600 mi) I, L								65
	DRIVE CHAIN					I			I		I	70
	DRIVE CHAIN SLIDER					I		R	I		I	14
	BRAKE FLUID	NOTE (3)				I		I	I		I	79
	BRAKE PAD WEAR					I		I	I		I	14, 79
	BRAKE SYSTEM					I			I		I	14, 79
*	BRAKE LIGHT SWITCH							I			I	--
*	HEADLIGHT AIM							I			I	--
	CLUTCH SYSTEM					I		I	I		I	18
	SIDE STAND							I			I	71
*	SUSPENSION							I			I	--
*	NUTS, BOLTS, FASTENERS					I		I			I	--
**	WHEELS/TYRES							I			I	--
**	STEERING HEAD BEARINGS					I		I			I	--